

Quick guide Nokia 1112

Making a call Enter a phone number and press the Talk key (Green key).

Answering a call Press the Talk key (Green key).

Ending a call Press the End key (Red Key).

Declining a call Press the End key.

To Redial Press the Talk key twice.

Turning the call volume up or down

Press the scroll key to the right to increase the volume while on the call

Press the scroll key to the left to decrease the volume while on the call

Turning the call volume up or down

Press "Menu"

Scroll to **Settings**, press "Select"

Scroll to **Tone settings**, press "Select"

Scroll to **Ringer volume**, press "Select"

Scroll to volume setting, press "OK"

Changing the ringtone

Press "Menu"

Scroll to **Settings**, press "Select"

Scroll to **Tone settings**, press "Select"

Scroll to **Ringtone**, press "Select"

Scroll to ringtone, press "OK"

Writing and sending a text messages

Press "Menu"

Scroll to **Messages**, press "Select"

Scroll to **Create message**, press "Select"

Enter text, press "Options"

Scroll to **Send**, press "Select", press "Search" or enter phone number

Scroll to contact, press "OK"
Press "OK"

Adding someone's name and number to my phonebook

Press "Menu"
Scroll to **Contacts**, press "Select"
Scroll to **Add contact**, press "Select"
Enter name, press "OK"
Enter phone number, press "OK"
Scroll to caller icon, press "Use"

Calling someone whose number is saved in my phone

Press "Menu"
Scroll to **Contacts**, press "Select"
Scroll to **Find**, press "Select"
Press "List"
Scroll to contact, press "Options"
Scroll to **Call**, press "Select"

Locking the keypad

Press Menu followed by the * Key.
To unlock the keypad press Unlock followed by the *Key